



Quad Series Instruction

Navigator Quad – Pairing a Remote

1. Disconnect the battery
2. Hold down the Stop Button on the Remote until both the Lock and Unlock buttons are illuminated – then release the Stop Button.
3. Reconnect the battery
4. The Remote will synchronise with the Top Box – the process will be complete once the Lock and Unlock buttons are no longer illuminated

Please note, if you do not connect the Navigator with a battery, the Remote will exit Pairing after one minute.

MGI

Head office: 11 Maurice Crt, Nunawading VIC Australia 3131
T: 1300 644 523 P: + 61 3 8872 6700 E: info@mgigolf.com www.mgigolf.com