


# PARTS LIST

GC00609604

- A Hand Grip with Mount for Umbrella Holder
- B Scorecard Holder
- C Handle Frame Tube
- D Adjustable Handle Mechanism
- E Upper Bag Bracket
- F Adjustable Bag Strap
- G Joint
- H Main Upper Frame Tube
- I Main Lower Frame Tube
- L Wheel Connection Cam Lock
- M Lower Bag Bracket
- O Folding Lever
- U Bottom Bag Bracket
- W Wheel / Tire
- W<sub>1</sub> Front Wheel
- X Beverage Holder
- Y Foot Brake
- Z Cooler Bag



# ASSEMBLY INSTRUCTIONS




FIG. A




FIG. B




FIG. C




FIG. D




FIG. E




FIG. F




FIG. G

## TO SET UP THE GOLF CART

1. Slightly open the cart to the end until there is “click” sound.(Fig.A)
2. Release the cam lock of handle mechanism(Part.D) to open the handle.(Fig.B)
3. Insert wheel axle into the plastic hollow, by releasing the cam (Fig.C), and lock.
4. To engage the brake(Part.Y), step down the brake lever; to release the brake, raise up the brake lever.(Fig.D)
5. Adjust the handle height by operating the handle mechanism cam lock. (Part. D)(Fig.E)
6. Put golf bag onto the cart, and secure the bag with the adjustable bag straps.
7. Make sure to secure the bag in place and all screws are engaged before usage.
8. Fold the cart by lifting the folding lever. (Part.O)(Fig.F). The side wheels would draw close automatically as folding.(Fig. G)